

Mounting instruction, SB000








SS001

1





Installation

o connect the power supply to the AC outlet and to the remote receiver box

Remote emitter

- o after connection, the blue light will be lightning
- $\circ\quad$ push the emitter side buttons and the motor unit will rotate
- o for using the up/down function connect the wires to the motor output 1
- o for stopping the motion one of the buttons need to be pushed

Learning

 \circ if the remote receiver do not respond when pushing the emitter buttons, reset the receiver. After that, code the emitter and receiver together again

Coding

- o push the learner button on the receiver for less than 1 sec.
- o push one of the emitter buttons
- o the red light will start flashing
- o push one of the emitter buttons again and the red light will turn off
- o the units now are coded together with a unique code

Reset

 push and hold down the learner button on the receiver for 10 sec. (will be reset when the red light turns off).

Trouble shooting

- o check the plug connections
- o check whether the blue light is on
- o reset the receiver and make a new coding

316010.1